

FLARING TOOLS



FR-195 3/16", 1/4", 5/16", 3/8", 7/16", 1/2" & 5/8"

FR-395 4, 6, 8, 10, 12, 14 & 16MM



FR-203 5/8", 3/4", 7/8" & 1-1/8"

FR-103 3/4", 7/8" & 1"



FR-300 3/16", 1/4", 5/16", 3/8", 1/2" & 5/8"

FR-300M 6, 8, 10, 12, 15 & 16MM



FR-500 3/16", 1/4", 5/16", 3/8", 1/2" & 5/8"

FR-500M 6, 8, 10, 12, 15 & 16MM



Eccentric Cone Type Flaring Tool

FR-806A 1/4", 5/16", 3/8", 1/2", 5/8" & 3/4"

FR-806M 6, 8, 10, 12, 16, 19MM

FR-808A 3/16", 1/4", 5/16", 3/8", 1/2", 5/8" & 3/4"

FR-808ML 4, 6, 8, 10, 12, 16, 19MM



FR-525 3/16" to 5/8" (4.7-16mm)

One opening holds all sizes